



9000/1100T Silicone Boost Hose

- Remove hood
- Remove the plastic cover on the left side of the snowmobile that covers the turbocharger. There are 4 torx head screws
- Loosen intercooler boost hose clamps (upper and lower) and disconnect hoses from intercooler end tanks, turbo charger and throttle body.
- Install the new EVO hoses and T bolt clamps – make sure the clamps are clocked in such a way that they will not interfere with the throttle cable, side panel, or hood fitment. There are 3 smaller and one larger T bolt clamp. The larger end of the upper boost hose attaches to the throttle body. If the hose is difficult to install, spray brake cleaner on the throttle body and the inside of the silicone hose.
- If the hoses were purchased with an intercooler fan kit, some trimming of the lower hose where it connects to the intercooler may be necessary.
- Reinstall side panel and hood.

Thank you for choosing Evolution Powersports products. If you require further assistance, please call our Tech Support @ (715) 247-3862

***Note:** This product is exempt from the emission standards and related requirements of 40 C.F.R. § 1051 as provided by 40 C.F.R. § 1051.620, and California law [e.g., vehicle code §§ 27156 and 38391]. This product is sold only for use in connection with EPA certified, purpose-built, nonroad vehicles used solely for closed course, nonroad competition/racing and not used for any recreational purpose or on public highways or right of ways maintained by and open to the public. This product is sold only in connection with machines that do not fall under state and/or federal noise or emission standards/regulations. Purchasers who/that purchase this product represent and warrant that the product is purchased only in connection with EPA -certified, emission-regulations-exempt and noise-regulations-exempt competition/racing vehicles as interpreted under applicable state and/or federal law. Questions: Call Evolution Powersports at (715) 247-3862.*