



1/19/2014

EVO TURBO TO HEADER LOCKING FASTENER KIT FOR 1100T/Z1

1. You will need an 8mm 12 point socket or wrench.
2. The tab for the REAR PTO bolt will need to be bent over prior to installation – see below.
3. Install bolts with a washer underneath
4. Once bolts are installed and properly torqued, install the locking tabs as shown below.
5. Install C clip on each bolt.

