



Maverick R Front Grille Assembly

SKU(s): 925FC0752

INCLUDED PARTS

(1) Front grille, Black
(1) Backer Plate, Raw
(3) M4 Screw
(3) M4 Nyloc Nut
(2) M6 Screw

REQUIRED TOOLS

7mm Socket
T-30, T-15 Socket
4mm Allen



Step 1: Install the backer plate to the grille, use M4 hardware. Use a 7mm socket and T15.



Figure 1

Step 2: Remove the OEM grille by pulling straight out, out of (4) clips.



Figure 2

Step 3: Remove (2) T-30 screws on lower part of grille.



Figure 3

Step 4: Remove (2) T-30 screws on the upper part of the grille.



Figure 3

Step 5: Install the upper part of the grille first, making sure it's above the black plastic but below the nutsert in the hood plastic. Use supplied M6 hardware, reuse the OEM washers for the top. Reuse the OEM hardware for below.



Figure 4

Thank you for choosing Evolution Powersports products. If you require further assistance, please call our Tech Support @ (715) 247-3862

Note: This product is exempt from the emission standards and related requirements of 40 C.F.R. § 1051 as provided by 40 C.F.R. § 1051.620, and California law [e.g., vehicle code §§ 27156 and 38391]. This product is sold only for use in connection with EPA certified, purpose-built, nonroad vehicles used solely for closed course, nonroad competition/racing and not used for any recreational purpose or on public highways or right of ways maintained by and open to the public. This product is sold only in connection with machines that do not fall under state and/or federal noise or emission standards/regulations. Purchasers who/that purchase this product represent and warrant that the product is purchased only in connection with EPA -certified, emission-regulations-exempt and noise-regulations-exempt competition/racing vehicles as interpreted under applicable state and/or federal law. Questions: Call Evolution Powersports at (715) 247-3862.