



Polaris Pro R Rear Facia

SKU(s): 925FP0184

INCLUDED PARTS

(1) Pro R Rear Facia
(2) M4 Stainless Screw
(2) M4 Stainless Nut
(2) M5 Stainless Screw
(2) M5 Stainless Nut
(4) M5 Stainless Washers

REQUIRED TOOLS

M4 & M5 Allen Wrench
10 & 13mm Open End Wrench
T50 Socket
Ratchet



Step 1: Open the new Pro R rear Facia box. Place the raw aluminum backer plate onto the rear facia trim. Use the M4 hardware and install. Keep the head of the screws on the outside.



Step 2: With a T50 socket remove the (2) screws holding the rear facia to the frame. Keep the plastic step washers.



Step 3: Place the EVP facia trim piece onto the vehicle. Reuse the OEM plastic step washer and bolt. Start securing but leave somewhat loose.



Step 4: Install the remaining hardware through the OEM plastic tabs. Place a washer on the head and nut side. Fasten down. Also finish fastening the T50 screws.





Thank you for choosing Evolution Powersports products. If you require further assistance, please call our Tech Support @ (715) 247-3862

Note: This product is exempt from the emission standards and related requirements of 40 C.F.R. § 1051 as provided by 40 C.F.R. § 1051.620, and California law [e.g., vehicle code §§ 27156 and 38391]. This product is sold only for use in connection with EPA certified, purpose-built, nonroad vehicles used solely for closed course, nonroad competition/racing and not used for any recreational purpose or on public highways or right of ways maintained by and open to the public. This product is sold only in connection with machines that do not fall under state and/or federal noise or emission standards/regulations. Purchasers who/that purchase this product represent and warrant that the product is purchased only in connection with EPA -certified, emission-regulations-exempt and noise-regulations-exempt competition/racing vehicles as interpreted under applicable state and/or federal law. Questions: Call Evolution Powersports at (715) 247-3862.