

## **Pro XP Bed to Airbox Reinforced Intake Tube Kit**

**SKU(s): 203FP0071**

### **INCLUDED PARTS**

- (1) EVP Reinforced Intake Tube
- (2) 80-100 Worm Drive Clamps

### **REQUIRED TOOLS**

- 7mm Socket

### **INSTALLATION STEPS:**

**Step 1:** Loosen the OEM clamps (7mm socket) holding the stock tube onto the airbox and fresh air inlet.

**Step 2:** Remove the stock tube from the vehicle.

**Step 3:** Install the new clamps on the new intake tube.

**Step 4:** Install new hose and tighten clamps.





## INSTALLATION INSTRUCTIONS

Thank you for choosing Evolution Powersports products. If you require further assistance, please call our Tech Support @ (715) 247-3862

**Note:** This product is exempt from the emission standards and related requirements of 40 C.F.R. § 1051 as provided by 40 C.F.R. § 1051.620, and California law [e.g., vehicle code §§ 27156 and 38391]. This product is sold only for use in connection with EPA certified, purpose-built, nonroad vehicles used solely for closed course, nonroad competition/racing and not used for any recreational purpose or on public highways or right of ways maintained by and open to the public. This product is sold only in connection with machines that do not fall under state and/or federal noise or emission standards/regulations. Purchasers who/that purchase this product represent and warrant that the product is purchased only in connection with EPA -certified, emission-regulations-exempt and noise-regulations-exempt competition/racing vehicles as interpreted under applicable state and/or federal law. Questions: Call Evolution Powersports at (715) 247-3862.

WE'D LOVE TO HEAR FROM YOU - LEAVE A REVIEW & STAY CONNECTED!   