

X3 Billet Shift Knob

SKU(s): 925FC0005

INCLUDED PARTS

(1) EVP Billet Shift Knob



REQUIRED TOOLS

13mm Open End Wrench

Medium Strength Thread Lock

INSTALLATION STEPS:

- **Step 1:** Use your 13mm wrench to loosen the jamb nut underneath the stock shift handle.
- **Step 2:** Turn the factory shift knob counterclockwise to remove. Note: The handle was installed with thread lock and may require some leverage to loosen.
- **Step 3:** Turn the jamb nut down to the bottom of the shift lever.
- **Step 4:** Use a small amount of medium strength thread lock and thread the EVP Shift Knob onto the shaft until it lightly seats.
- **Step 5:** Position the EVP Knob so it comfortably fits your hand then tighten the jamb nut.







Thank you for choosing Evolution Powersports products. If you require further assistance, please call our Tech Support @ (715) 247-3862

Note: This product is exempt from the emission standards and related requirements of 40 C.F.R. § 1051 as provided by 40 C.F.R. § 1051.620, and California law [e.g., vehicle code§§ 27156 and 38391]. This product is sold only for use in connection with EPA certified, purpose-built, nonroad vehicles used solely for closed course, nonroad competition/racing and not used for any recreational purpose or on public highways or right of ways maintained by and open to the public. This product is sold only in connection with machines that do not fall under state and/or federal noise or emission standards/regulations. Purchasers who/that purchase this product represent and warrant that the product is purchased only in connection with EPA -certified, emission-regulations-exempt and noise-regulations-exempt competition/racing vehicles as interpreted under applicable state and/or federal law. Questions: Call Evolution Powersports at (715) 247-3862.