

X3 Clutch Cover Quick Change Pin Kit, 4 Lanyard

SKU(s): 404FC0005

INCLUDED PARTS

(1) Quick Change Pin Kit

REQUIRED TOOLS

Rivet Gun

1/8" Drill Bit

INSTALLATION STEPS:

Step 1: Remove clutch cover

Step 2: Install one pin in each screw hold on the housing. Screw them in until you can no longer see the threads on the pin.

Step 3: On the flat spot on the cover, mark your holes centered between two pins for drilling. You should use one rivet for two leashes. See picture below.

Step 4: Remove the cover and using a 1/8" drill bit to drill your holes.

Step 5: Use a rivet gun to install 2 leash per hole. Use provided washers on the back of the rivet, so it does not pull through the plastic.





INSTALLATION INSTRUCTIONS

Thank you for choosing Evolution Powersports products. If you require further assistance, please call our Tech Support @ (715) 247-3862

Note: This product is exempt from the emission standards and related requirements of 40 C.F.R. § 1051 as provided by 40 C.F.R. § 1051.620, and California law [e.g., vehicle code §§ 27156 and 38391]. This product is sold only for use in connection with EPA certified, purpose-built, nonroad vehicles used solely for closed course, nonroad competition/racing and not used for any recreational purpose or on public highways or right of ways maintained by and open to the public. This product is sold only in connection with machines that do not fall under state and/or federal noise or emission standards/regulations. Purchasers who/that purchase this product represent and warrant that the product is purchased only in connection with EPA -certified, emission-regulations-exempt and noise-regulations-exempt competition/racing vehicles as interpreted under applicable state and/or federal law. Questions: Call Evolution Powersports at (715) 247-3862.

WE'D LOVE TO HEAR FROM YOU - LEAVE A REVIEW & STAY CONNECTED!   