

Bowaters Models – BMGA Series Instructions GWR Collett Coach Bogies



Requires

• Slaters Plasticard 1:32 Wagon Wheels

Required Tools

- Fine Sandpaper/Emery paper or boards
- Small Files
- PVA Glue
- Super Glue
- Sharp Craft Knife

Prototype Information

These are the GWR Collett Passenger Coach Bogies available in both 7ft and 9ft lengths off our standard kits made available for scratch builders to place their own bodies on top of the them.

About the Kit

The kit is a wooden kit comprising of a set of laser cut wooden parts and 3D printed sections.

<u>Instruction notes</u>

With these instructions, there are images which show various stages of the construction of one of the kits. They are of the Test build for BMGA-004 which isn't representative of the kit you have brought. They are for reference purposes only.

Painting

For painting, it is recommended you refer to prototype images to ensure the models are in the condition that you model (Pregrouping, Grouping or Nationalisation).

Please Turn over

Please read though these instructions before beginning to assemble your kit



Start by gluing the bogie core together between the two bogie sides.



Now slide the bearings and wheels into place. There is enough give in the bogie to fit them without any issues.



Now, glue into place the springs......



..... followed by the axlebox covers.



To complete the bogie, glue into place the bogie stretchers which hold the ends together.



To mount the bogie, assemble the mounting point formed of 2 small and 1 large circle with the mounting hole in the middle.



Next glue into place the bogie mount on the underside of the model then screw the bogie in place.

Your bogies are now complete.



We hope you enjoy your Bowaters Models kit! If you have any questions, don't hesitate to contact us on info@bowatersmodels.co.uk

We thank you for your custom.