



Installation Instructions

FBM850V

The NoviStretch™ FBM850V mask is easily secured using snap fasteners integrated into the design. This requires snap-head screws, supplied in the hardware kit, be installed on the car as described below. The initial installation should require approximately 15 minutes to complete. After setup, the mask can be quickly & easily installed and removed.

The FBM850V is designed for installation on all 2020 and later 8th Generation "Mid-Engine" Corvettes.

Enclosed you will find:

- FBM850V Mask
- Hardware Kit containing nine (9) snap-head screw studs
- Installation Instructions & Warranty Information

Tools Required:

- #15 and #20 Torx head wrenches

STEP 1

Clean the bumper, fender wells, and surfaces under the car thoroughly. Tar and grease remover is recommended.

STEP 2



Turn the front wheels to gain easier access to the fender liner mounting screws that you will be replacing.

STEP 3



Locate the four (4) mounting screws at the edge of the bumper inside the fender liner and remove them. Replace each one as you go with the supplied snap-head screw studs. Repeat this step on the other side of the car.

STEP 4



Begin the mask installation by fastening the top 2 snaps on one end of the mask to the screws just installed on the edge of the bumper.

STEP 5




Stretch the mask across the front of the bumper, being careful not to rub the plastic clips against the paint. Attach the 4 snaps to other side of the car and the remaining 2 snaps on the original side.

▲ Note: The tension in the mask is normal and important to the overall performance of the product.

(Instructions continue on other side)

STEP 6



Pull the bottom edge of the mask down under the bumper, noting the position of the snap on the bottom-center edge of the mask. Replace the screw on the bottom of the bumper that best aligns with the snap on the mask with a snap head screw stud. Fasten the snap on bottom of the mask to the screw just installed on the bottom of the bumper.


STEP 7



Open the "frunk" hood and locate the bump-stop wells at each corner of the frunk shroud. Holding the top of the mask, pull it up to the hood opening and secure the clip at the corner of the mask into the opening in the recessed well. Repeat this step for the other corner of the mask.



STEP 8



▲ Note: When closing the frunk, make sure the top edge of the mask does not cover the latch opening or in any way interfere with the full and secure closing of the frunk.

If necessary: 1) Slightly pull the mask back while carefully closing the frunk; 2) Pull the hood down and set the striker gently into the latch; 3) Release the mask edge and firmly press down on the front edge of the hood until the latch clicks twice. Check that the hood is flush to the fascia to ensure the hood is fully closed.

Front License Plate Installation

A license plate can be installed over the mask without causing harm to the mask. The small holes made by mounting screws will not cause the fabric to "run." Thumbscrews may be used to make removal of the license plate more convenient.

Protecting Your Investment

NoviStretch® covers are constructed from synthetic stretch fabric that will not chaff or damage the painted surface and have been designed to perform in all weather and road conditions.

It is **important** that the painted surface be clean prior to installation of the cover. Over time and use, dirt or dust may work its way between the cover and the painted surface. Regular cleaning of both the cover and surface is **essential** to provide proper protection. Severe weather conditions or travel on off-road surfaces increase the recommended frequency for inspection and cleaning.

It is expected to see some cosmetic damage (small holes, thinning, fading or discoloration) to the mask over time & miles as it does its job. However, proper care will maximize product life.

NOVIGO DESIGNS™ TWELVE (12) MONTH LIMITED WARRANTY Novigo Designs, LLC warrants this product against "defects in material and workmanship" for a period of twelve (12) months from the original date of purchase by the original consumer purchaser. For full details and explanation of warranty coverage, requirements and policy, please go to the "Support" section of www.NoviStretch.com. Novigo Designs (and its authorized distributors) liability is limited to the materials and workmanship of the product. Novigo Designs is not responsible for damage caused by the product to the paint or finish of the vehicle. To avoid any possible damage and to get the maximum benefit from your Novigo Designs product, carefully follow the installation and care instructions provided. Novigo Designs, LLC.

Notice: Patent Pending; NoviStretch™ Copyright © 2020 Novigo Designs, LLC. All Rights Reserved.

Cleaning & Care Instructions

- The mask can be cleaned by rinsing in water to remove any dirt or debris, squeezing the water out and letting air-dry.
- Wash (by hand) only as necessary. Use a concentrated soap solution on areas of the mask that may be particularly dirty.
- Do not use any solution containing bleach. Do not use a clothes dryer to dry the mask.
- Always ensure areas covered by the mask are clean and free of sand and grit before installing the mask.
- Avoid obstacles and low-clearance areas in the roadway that may come in contact with the bottom of the car causing the mask to snag and the material to tear.