

# Oberon Pendant

4055 – INSTALLATION INSTRUCTIONS



Thank you for your Fuse Lighting purchase. Installation is rather simple but should be done by a professional electrician and one assistant. Please read instructions completely prior to installation. These installation instructions are intended as a reference guide only. Unique site conditions may require installer to deviate from installation steps listed.

## ONE - SECURE MOUNTING PLATE TO CEILING

- Remove blindmount screws from sides of canopy, and remove mounting plate. Set blindmount screws aside.
- Secure mounting plate to J-box using two J-box screws.

## TWO - WIRE AND MOUNT PENDANT

- Wire pendant to J-box and mount canopy to mounting plate with blindmount screws previously set aside.

## THREE - ADD BULBS

- Bulbs are provided as a one-time courtesy when in stock. If recommended bulbs are not available when your order is complete, fixture will ship without bulbs. This is to avoid delays in shipping.
- We recommend using a clear T-6 candelabra base bulb.

## FOUR - INSTALL GLASS SHADES

- Carefully hang glass shade from top horn first, then slide bottom of glass shade onto bottom horn. Hanging shade requires a very delicate touch, and will require you to maneuver the shade carefully so that each hole aligns with shade horns as you slip shade onto sconce.
- Every glass shade is individually mouth-blown and will vary slightly in shape and size. We test and label each shade prior to shipping. If your order includes multiple Oberon sconces, please match each glass shade to each sconce frame.
- Apply clear vinyl ring to bottom of each shade arm to further secure glass shades in place.