

Novepoxy Application Tips

February 2019

- All paint tools to be paint free e.g. new drill, sleeves, brush, tray.
- When painting a floor always best that at least two people apply the coating. 1 to cut in and 1 to roll or spray.
- Air movement is very important when the product is drying. Fans, doors, or have windows open.
- High levels of humidity will affect the drying and sheen of product.
- Unless experienced with two pot products it is best not to alter the pack size.
- Foam rollers are a good application if doing cabinets, benches.
- Colours will appear lighter when wet or just applied.
- Concrete floors that have a rougher surface profile could use more product and might require to be left longer for re coat times. This is dependent on ambient atmosphere temperature and humidity levels.
- Both pack contents must be mixed together to ensure even mixing drill mix on low for at least 2 mins or hand mix with a clean flat stick. Do not mix too vigorously as product will become aerated.
- All paint gear should be washed immediately in warm soapy water. Do not leave submerged in water without washing.
- Concrete floor profile for painting should have a 150-180 grit for adhesion.
- Clear Novepoxy is not recommended over white colours.