

USER GUIDE AND INSTALLATION MANUAL

FRENCH HEADLIGHT KIT

AUTFRHEAD

PRIOR TO CUTTING

1. Determine headlight Placement 8" diameter and 5⁵/₈" deep.
2. Cut 8" Hole in Fender
3. Insert bucket into hole with Center tab at 12 o clock.
4. Double check for clearance prior to welding.
5. Once desired placement has been reached, weld bucket ring to fender while being sure not to warp the bucket.
6. Place Rings around the headlight and align the holes with the tabs located in the bucket. Mark and drill holes in the tabs for the screws.
7. Insert screws through the ring holes and place the springs in between the rear ring and each tab inside of the bucket.
8. Adjust the screws to reach the desired angle position of the headlight beam.
9. Snap the trim ring in place.

