

HIDEAWAY

GATE

Assembly Manual

English

STEP 1. BEGIN BY PLACING THE POSTS IN THE DESIRED LOCATION, ENSURING PRECISE MEASUREMENT OF THE DISTANCE BETWEEN THEM. TAKE INTO ACCOUNT THE 1/2" GAPS ON BOTH SIDES OF THE GATE FOR THE LATCH AND HINGES.

STEP 2. ONCE YOU HAVE VERIFIED YOUR MEASUREMENTS, SECURELY FASTEN THE BASE PLATE USING FOUR GRK SCREWS THROUGH THE PREDRILLED HOLES AND INTO WOOD. NOTE THAT GRK SCREWS NEED TO BE PURCHASED SEPARATELY. IF MOUNTING THE GATE ON CONCRETE, UTILIZE CONCRETE WEDGE ANCHORS INSTEAD.

STEP 3. POSITION THE GATE AT A HEIGHT OF APPROXIMATELY 4" ABOVE GROUND LEVEL (THIS IS THE RECOMMENDED GAP, BUT IT IS NOT MANDATORY).

GATE IS TO BE MOUNTED FLUSH WITH FRONT SURFACE OF POSTS.

HINGES MOUNT TO THE FRONT OF GATE & POST SURFACE AS SHOWN.

[NOTE: LOCATION OF HINGE PLACEMENT IS AS DESIRED.]

RECOMMENDED SPACE FROM BOTTOM/GROUND LEVEL IS 4".

ALIGN POSTS SO THAT THEY ALLOW FOR 1/2" GAPS FOR THE LATCH AND HINGES.







Technical Support

Get in touch with us and we'd love to answer all your questions or comments. We have our team ready to help with anything you need.

info@hideaway.inc
+1 866-933-6833

@HIDEAWAY_INC 
HIDEAWAYSCREENS.CA 

HIDEAWAYCANADA.COM 

HIDEAWAYUS.COM 