

## BEAD BREAKER & PUMP CHART

BEAD BREAKER APPLICATION GUIDE

		NA	NA	10201	10200	NA	10202	10839	10825	NA
		NA	NA	NA	10230	NA	10237	10821	10820	NA
		NA	NA	NA	10221	NA	10233	10841	10826	NA
		NA	NA	NA	10228	NA	10220	10847	10832	NA
		NA	NA	NA	10229	NA	10223	10848	10837	NA
		10213*	NA	10206	10205	NA	10222	10844	10829	NA
		10204*	NA	10208	10207	NA	10209	10838	10824	NA
		NA	NA	NA	10231	NA	10238	10823	10822	NA
		10224*	NA	NA	10212	NA	10235	10843	10828	NA
		NA	NA	NA	10227	NA	10234	10842	10827	10211
		NA	NA	NA	40610	NA	40613	40619	40616	NA
		NA	NA	NA	40611	NA	40614	40620	40617	NA
		NA	NA	NA	40612	NA	40615	40621	40618	NA
		NA	NA	NA	10203	NA	10236	10845	10830	NA

\*10601K NOT INCLUDED

### BEAD BREAKER APPLICATION GUIDE

- SINGLE PIECE RIM
- 2 PIECE RIM
- 3 PIECE RIM
- 5 PIECE RIM
- ALL WHEEL ASSEMBLIES



### BEAD BREAKER KITS COME WITH:

- 10604 - 8 ft. Hose assembly (10610) with Hose Coupler (10605)
- 10601K - **NEW** Air Reducer & 6" Whip Hose

BEAD BREAKER & PUMP APPLICATION CHART IS BASED ON CONFIGURATION NOT BY RECOMMENDED USAGE. PLEASE CONSULT WITH AN ESCO SALES REPRESENTATIVE FOR MORE INFORMATION ABOUT APPLICATION & KIT CONFIGURATIONS.