

Design lover, behold the arrival of your Krane Home wallpaper!

We are so excited to help you completely transform your space to reflect your personal style. Be sure to tag us @kranehome so we can share how you brought your vision to life!

Krane Home wallpaper is hand-screened with water-based ink on high quality clay coated ground. We recommend installation by a skilled professional paperhanger.\*

## HANGING INSTRUCTIONS

### step 1:

Before hanging your wallpaper, make sure that the surface is clean, smooth, and dry. Old wall coverings should be completely removed. A clear, non-staining, ready-mixed adhesive is recommended.

### step 2:

Our screen printed wallpaper is non-pasted and should be installed using a traditional hanging method. Paste the back of the wallpaper using a roller brush. Fold the pasted side together (aka 'book') and let stand for 5-7 minutes. This will keep the seams from opening up and drying out while the paper is setting.

## step 3:

Match the pattern on the wall at eye level and put the seams tightly against each other - do not overlap. Use a wallpaper brush or a smoothing tool to gently work the paper onto the wall working from the top and middle, down and out. All hand-screened papers suggest a 1/8" allowance in matching.

## step 4:

Clean with warm water and a sponge, taking care to remove all the paste from the surface. Rinse thoroughly a second time with clean, warm water. After hanging 2 strips, be sure to check for any defects before proceeding.

\*Please note, wallpaper cannot be accepted for return due to improper installation. Ensure rolls are undamaged and are the correct quantity, pattern, and color before you begin. It is the customer's responsibility to inform Krane Home of any incorrect or damaged product as no claims can be entertained for any part of the order after cutting and hanging.

# STILL HAVE QUESTIONS?

For quickest response email us at: studio@kranehome.com Phone: +1 (424) 291-2990 website: www.kranehome.com