

Range Hood Mounting Instructions



CHIMNEY RANGE HOOD INSTALLATION INSTRUCTIONS:

- 1) Locate available studs in area where the Chimney Range Hood is to be installed.
- 2) Align Chimney Range Hood so at least two screws will be secured through each mounting strip and into the available studs.
- 3) Refer to manufacturers guidelines that accompany stove/cooktop that will be located beneath Chimney Range Hood.
- 4) Exposed wood edges should be no less than 30" above cooking surface.
- 5) Mount Chimney Range Hood securely to wall using minimum #8 x 2-1/2" long framing screws.
- 6) Install ventilation power pack into steel liner as outlined in ventilator instructions.
- 7) Mount liner/ventilator assembly to inside of hood opening using available mounting holes and secure unit with wood screws (#6 x 1/2").
- 8) Install ductwork or ductless kit according to ventilation manufacturer's guidelines.
- 9) Install Chimney Extension over ductwork and fasten to the wall with framing screws, securing to studs where available. If studs are not present in mounting area, use drywall anchors.

