



## React Brackets for Snowden Seats - 67-72 C10

Thanks for your purchase of React components. Please ensure everything is in the box according to the list below. If not, contact us within 2 business days of receiving so we can help. If after 2 business days, it is difficult for us to ensure getting you the missing parts.

All React parts offer a lifetime warranty against manufacturer defect and craftsmanship. This warranty is voided if product is abused or has been improperly installed.

All React parts are for off-road use only.

### Parts Included

- (2) Seat brackets (left and right are the same design)
- (4) 5/16 Bolts
- (4) 5/16 Nyloc nuts
- (8) 5/16 Washers

Start by laying out all parts and accounting for all items listed above. Once you confirmed it is all there, we can proceed. Make sure to use all proper safety procedures and equipment when working on any vehicle. Failure to do so can result in injury or death.

1. Remove old / previous seat if it exists.
2. Bolt the React bracket into the factory seat floor mounts using the (4) bolts and (4) washers. The angle end of the bracket will face forward.
3. The bracket will use the the original front outside holes on the floor for the front bolt. The rear will bolt using the outside factory hole in the floor, going through the INSIDE rear hole in the bracket. Should look similar to the picture below.
4. Place seat onto the brackets and use the reminaing (4) washers and (4) nyloc nuts to secure to the bracket.
5. If using a 58" seat, you will use the inside holes closest to the center of the truck. If using with a 60" seat, then the outer holes closest to the outside of the truck will be used.

If you have any technical questions or issues with your React product, please contact us using the information below. Again, thank you for your purchase!

