

## CORRADO RAIN TRAY INSTALLATION

This product is made of high-quality carbon fiber composite. It has a clear gel coat finish that has UV protection to ensure it won't discolor from long term exposure to sunlight. It can be polished if scratched by using automotive or marine polishing products.

To begin the installation remove both upper and lower rain tray seals. Next you will need to trim the plastic cover that fits over the HVAC air inlet. This can be done without removing it from the car. Please refer to the two pictures included in the instructions and trim where the red line is. This will allow the rain tray to fit over the plastic cover.



### TRIM PLASTIC HVAC INLET COVER ON THE MARKED RED LINES

Next install the rain tray into the car making sure that it fits tight towards the passenger side of the car. This will allow enough clearance for the drivers side hinge and the attachments located on it. The front lip of the rain tray closest to the engine should fit snug against the metal lip of the car. The rear lip of the rain tray should fit flush with the plastic trim at the base of the windshield. We suggest using black electrical tape along the rear lip lengthwise and folding it over both lips while pulling the lips tight together. This will help the installation of the rubber seal and keep the lips from separating. The rear seal can be opened up by using a flat blade screwdriver in a twisting motion on the open end of the seal. We suggest rolling the seal on rather than pressing straight down. The front seal is easy to install and can simply be pressed straight on.

Thank you for your business!