



## **Basic Room/Linen Spray Recipe**

### **Ingredients:**

**70% Water**

**20% Isopropyl Alcohol**

**0.5 % Optiphen plus (this can be omitted, but shelf life may be shortened)**

**7.5 % Polysorbate 20**

**2.5% fragrance**

### **Method:**

**Heat the water to 40 degrees and add the rest of the ingredients. Stir gently, until all ingredients are mixed well. Decant into bottles and attach a misting spray**