



LEV-O-GAGE™

PRODUCT INSTRUCTIONS

For use with all Lev-o-gage™ models:

- Lev-o-gage
- Lev-o-gage II
- Lev-o-gage 8
- Lev-o-gage Sr.

MOUNTING INSTRUCTIONS

Before mounting your Lev-o-gage™, move vehicle to a smooth area that you know is flat and level. You can ensure the vehicle is level with the use of a carpenter's level. Next locate a vertical or near-vertical mounting surface for the gauge. (For optimal accuracy, mounting area should be vertical.) Make sure the surface is clean and dry, and temperature is above 50°F / 10°C. After removing the thin backing from pressure-sensitive tape, hold the gauge so the indicator ball is at the "0" position on the gauge. Then carefully place your Lev-o-gage™ on the clean, dry mounting surface, using firm pressure to "set" the adhesive.

The special high-bond foam tape will permanently mount the gauge to almost any flat or slightly-irregular surface. If desired however, the gauge can be drilled and mounted with screws (not provided). Drill two 5/32" holes straight through the two small indentations on front of Lev-o-gage™.

Register your warranty by scanning the QR code:

Or visit:
suncompany.net/warranty



✉ support@suncompany.net

🌐 [@suncompany_](https://www.instagram.com/suncompany_)

📘 [facebook.com/SunCompanyInc](https://www.facebook.com/SunCompanyInc)

FAMILY-OWNED AND OPERATED
100% SATISFACTION GUARANTEED

SUN COMPANY, INC.
COLORADO, USA
WWW.SUNCOMPANY.NET