

Honda TRX90 A21 Hood Installation: Fitment 2006 or Newer

Remove your fender bolts on the sides of your shrouds, and it allows the plastics to come out a little more-free. At the tank area, you pull in the hood and put the push pins in place. It's a tight fit to get the proper fit with how the hood is shaped.

Then you move to the front. Pull down, line up your front plastics with the little notched area keeping inside of the plastics and then drill your holes and mount with the push pins. You can then put those bolts back in place.

On the TRX90, the stock hood sucks the plastics inward, and distorts the plastics. So when we made this hood, we wanted to allow the plastics to relax and be like how the TRX450r is, with the plastics coming straight down and staying the same width. Installed Pictures Below:

