



# All Sports Manufacturing Inc. Drive Spindle Lift Kit



**1-866-291-5244 | 3361 Copter Rd Pensacola, FL 32514**

# Drive Spindle Lift Kit

## Front

1. Replace Original Equipment Spindles With Supplied Lift Spindles.
2. Set Toe At 1/8"- 3/16" Inward At Front Of Tires.

## Rear

1. Remove Track/Sway Bar From Passenger Side Of Cart.
2. Raise And Support Rear Of Cart.
3. Remove Upper Shock Bolts.
4. Install Rear Lift Bracket (H Bracket) To Cart Frame With Supplied Bolts & Spacers.
5. Reinstall Shocks To Lift Bracket With O.E Hardware.

## Track/Sway Bar Bracket

1. Drill Existing Track/Sway Bar Mount Hole To 1/2" (O.E Is 12mm) To Allow For Positive Fit Of Bracket.
2. Install Bracket By Putting 5/16" Welded Pin Into O.E Mount Hole.
3. Install Supplied 1/2" x 1 1/2" Bolt .
4. Reattach Track/Sway Bar To Top Of Bracket.