



PASSENGER PEG ADAPTERS FOR INDIAN

WARNING This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

ATTENTION This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation. Read completely and understand the instructions prior to starting installation.

NOTE: Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a limited lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed, unmodified and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit Ciro3d.com for our complete warranty policy.

Included Parts



Installation Instructions:

1. Park on a level surface and shut off the motorcycle. Ensure that the engine has time to cool before installation.
2. Remove screw from passenger peg mount arm to facilitate the install of the adapter. Fig. 1
3. Remove spiral spring clip to release pin. This will not be reused. Remove pin and slide out stock foot peg. Fig. 2
4. Place spring D washer along upper side of mount arm with curve facing in and flat edge down. Fig. 3
5. Push adapter down alongside the washer until holes align. The curved side of the adapter will face back. Reinsert pin through top side of mount arm. Fig. 4
6. Install provided retainer clip onto pin. Fig. 5
7. Reattach mount arm to motorcycle. Fig. 6
8. Attach desired peg to adapter using provided screw and washer. Fig. 7
9. Repeat steps 2-8 on other side of motorcycle.



