

CHICANETM FOOTRESTS

WARNING

This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION

This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal

ATTENTION

This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation. Read completely and understand the instructions prior to starting installation.

NOTE: Ciro products are designed and manufactured under very strict quality control. Ciro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a limited lifetime warranty against LED failure. Ciro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed, unmodified and maintained. Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products. Please visit Ciro3d.com for our complete warranty policy.



Installation Instructions:

- 1. Park motorcycle on a level surface and ensure engine has time to cool before beginning installation.
- Attach clevis to footrest using provided screw and washer. Notches on clevis should point up. Do not tighten fully until final position is set. Fig. 1
- 3. Place footrest assembly into clevis using existing D spring washer and screw. Fig. 2
- 4. Adjust tilt of footrest at point 1 and the height at point 2 on the clevis. Fig. 2 Tighten all screws securely.
- 5. Repeat steps 2-4 on other side of motorcycle.







