



CIRO VENT TRIM

Parts Included:

- 1 Vented Trim Assembly
- 1 Y-Harness*
*Only included with lighted model

Installation Instructions:

1. Park on a level surface and shut off the bike. Ensure that the engine has had time to cool before installation.
2. If you've purchased the lighted version, feed the wire through the fairing vent from the front.
3. Test fit the vent to the fairing to figure out correct placement. Minimize any gaps around the edges and ensure the front point is flat against the fairing. Mark the sides and front with painters tape.



4. Prepare the surface of the fairing by cleaning with a wax remover/degreaser.

5. Rub the back side of the adhesive with your fingernail to activate it. Peel the backing off.

*If you are installing the lighted version, make sure that the wire is still fed through the vent. Do not let the wire get stuck between the trim and fairing.

6. Carefully line up the trim with your tape guides. Ensure there are no large gaps between the trim and fairing. Apply pressure to the trim for 30 seconds to adhere it to the fairing.

LIGHTED VERSION ONLY:

7. Remove the outer-fairing according to your HD service manual.

WARNING:

This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

CAUTION:

This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

ATTENTION:

This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Giro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation.

NOTE:

Giro products are designed and manufactured under very strict quality control. Giro warrants that products sold to the original purchaser shall be free from any defects in materials and workmanship for a period of 3 (three) years from the date of purchase, and a lifetime warranty against LED failure. Giro will have no obligation if the customer cannot show proof of purchase. Warranty will not be granted unless the part is properly installed and maintained. Giro will not be liable for any consequential and incidental damages, including labor, or non-Giro products. Please visit our website Ciro3d.com for our complete warranty policy.

CIRO3D.COM

8. Route the wire along the top edge of your fairing towards the "broke side" of the motorcycle.



9. Plug the wire into the OEM 12v accessory connector.

***If this plug is already being used, put the supplied Y-harness in-line with it.**

10. Check to see that the light is functional and re-assemble the fairing according to your HD service manual.

*** While re-assembling the fairing, keep in mind the wire placement and ensure that it cannot be seen through the vent. Take care not to pinch the wire during re-assembly.**