

# IGNITION SWITCH ACCENT

# Parts Included:

1 Ignition Switch Accent

# Installation Instructions:

- 1. Park on a level surface and shut off the motorcycle.
- 2. Use an ammonia based glass cleaner to wipe surface clean where adhesive will make contact.
- 3. Test fit Ciro Ignition Switch Accent to ensure adequate switch clearance.



4. Activate adhesive backing by rubbing with fingernail. Remove adhesive backing and carefully align Ciro Ignition Switch Accent in correct position. Press and hold firmly for 60 seconds. Adhesive fully cures within 24 hours.

#### WARNING:

This indication alerts you to the fact that ignoring the contents described herein can result in potential serious injury or death if not followed.

### CAUTION:

This indication alerts you to the fact that ignoring the contents described herein can or will result in material damage and/or personal injury.

#### **ATTENTION:**

This indication alerts you to the fact if you ignore this detail you will affect the performance or functionality of the product.

All Ciro products are designed for "easy assembly" and/or "plug and play". We recommend a competent mechanic install our products, using standard mechanical procedures to assure a safe and successful installation.

## NOTE:

Ciro products are designed and manufactured under very strict quality control. Ciro products are warranted to be free of defects in material and workmanship for I (one) year from date of purchase by the consumer.

Ciro will have no obligation if the customer cannot show proof of purchase.

Warranty will not be granted unless the part is properly installed and maintained.

Ciro will not be liable for any consequential and incidental damages, including labor, or non-Ciro products.

Please visit our website Ciro3d.com for our complete warranty policy.