ASSEMBLY INSTRUCTIONS BOSTON WHALER 16'/17' CONSOLE SEAT

Fig. 1

- Locate the main bench seat panel. This panel is made up of 3 long planks held together by 2 blocks. Turn this panel upside down so that the rounded end of the blocks are facing towards you as shown in Fig. 1.
- 2.) Locate the left and right panels and attach to main bench seat panel with screws provided. There is a notch cut into the left and right panels that the main bench panel fits into. Make sure the angled side of the left and right panels are facing towards you. Fig. 2. Closeup detail shown in Fig.3.
- 3.) Turn the unit over and locate the 2 handles. Position and fasten each handle as shown in Fig. 4. IMPORTANT: Cut and sand each plug before inserting it into screw hole so that the plug will not stick out further than the surface around it. Tap into place using a scrap block of wood and small hammer. This is a very important technique because if you try sanding the plug down flush after it is inserted you run the risk of sanding through the veneer of the surrounding area. Sand entire console very lightly as to not sand through the outer layer of veneer and apply varnish as directed by the varnish mfg. Varnish can be brushed or sprayed on.
- 4.) This seat simply fastens to the front of the console with 4 #12 x 1 1/2" stainless wood screws. It is also fastened to the deck with 4 #14 x 2" stainless wood screws. Enjoy!



Fig. 2



Fig. 3



Fig. 4

