Sport 11' Installation Instructions (w/o console - single bench seat)

1. Prior to installing any wood in the boat, you will want to pre-drill the pair of seat clamps. These are the side rail pieces that hold the seats and console. Typically, you will use your old clamps as templates to determine the location of the holes. However, if you don't have your old clamps, not to worry. Simply drill 4 holes on each clamp evenly spaced.

2. Place the pair of clamps in the boat in the desired location. This does not need to be identical to your old setup, if you desire to place it further forward or backward to fit your needs.

3. Once the clamps are in place, mark their location and drill pilot holes into the fiberglass. Place the bench seat underneath the clamp slots and then fasten the clamps with the provided #12 x 1.5" screws and washers.