

### **ALTERNATE INSTRUCTIONS USING SCREWS**

You can also use a screw to through-bolt through the front and/or rear rail upright by drilling a hole through both walls of the rail and then securing it to the inside gunnel of the boat with a #12 x 1 1/2" or 2" screw. You will want to use some 3M 5200 on the screw so that it can anchor into the sidewall of the boat.