

Installation Instructions from WhalerCentral.com

Start out by placing one set of the rod holders near the bottom of the Black Stripe on the console or the bottom of the windshield and place the Top block about a 1/2" from the outside edge of the console. Drill the two upper holes and insert the bolts temporarily.

Align the rod holder tube so it is vertical making sure the bottom block is parallel to the upper block. Drill the two holes through the lower block.

Take one of the loose rod tubes and place 2 bolts through it and install it on one side of the blocks. Take another rod tube and do the same for the other side. Place the nuts and washers on the inside of the console and tighten down.

Do the same procedure for the other set of Rod Holders for the other side.

Rod Holder Placement on Console

