



PRODUCT SPECIFICATIONS

HTVRont

Application instructions (home iron)

- Set iron dial between Cotton and Linen
- Cover design with Baking Paper or non-stick cover sheet
- Place on flat, hard surface (ironing board not recommended)
- Press iron with firm pressure (do not slide iron)
- Press each section of design for 10-15 seconds
- If areas of design lift after application, replace cover sheet and re-press for 5-10 seconds
- Peel carrier cool

Application Instructions (heat press)

- Preheat garment for 2-3 seconds
- Apply design at 305 - 320°F
- Use firm pressure for 10-15 seconds
- Peel carrier cool

Wait at least 24 hours before washing

Applies to: 100% cotton, 100% polyester, Poly/cotton blends, Blend, Clothing, Fabric, Leather etc. NOTE: **Not** suitable for black polyester fabric.