



FS Performance Engineering

BMW 335i (e92) Side Skirt Extensions Installation Instructions

Installation is definitely easier on a lift. We recommend it.

Tools Needed:

- 8mm wrench/socket
- 10mm wrench/socket
- Torx 30 (T30) wrench/socket
- 1/4" Drill bit
- Cordless/hand drill
- Painter's masking tape
- Pen/sharpie
- A friend (hopefully not a tool)

Included in Kit:

- (2) Side Skirt Extensions
- (20) 1" OD Fender Washers
- (20) M6-1.0 x 20mm Bolts
- (20) M6 Nyloc Nuts
- (20) 1/4" Small Washers

Steps:

1. Raise car and secure with jack stands, or put it on a lift!
2. Starting on the passenger side place painter's tape underneath the rocker panel. Cover the entire underside. You will be marking the positions for the holes in the side skirt later. (3 PICS)





3. Remove the plastic undertray to the inside of the rocker panel. There will be several T30 screws, 10mm plastic nuts, and 8mm screws holding it on. (3 PICS)





Removed:



4. Hold one of your side skirt extensions up to the rocker panel and position it so the holes in the skirt line up with either flat parts, or rounded parts (where the angled portions of the rocker panel meet) on the rocker panel. If you place a hole in the rocker panel where there is an angle (or where it is flat but the rocker panel is angled) you may run into a little bit of curvature on the skirt extension later. No big deal as it wasn't for us, but some are more particular. :)

Go ahead and mark your holes onto the rocker panel. We started with one hole at the front, drilled it, loosely attached the side skirt, then marked the rest and drill them. Remove the painter's tape.

Attach your side skirt with 20mm bolts pointing upward + 1" OD fender washers on bottom, and 1/4" small washers + nyloc nuts on top. Tighten securely.









5. Reinstall your underbody panel.

6. Repeat steps on the driver's side of the car.

7. Enjoy your new FS Performance Engineering side skirt extensions! Remember to send us pictures once they are installed.



For questions email costas@fspeinc.com or jim@fspeinc.com
Or call/text us at (661) 809-0954