



FS Performance Engineering
Ford Focus ST (2015+) Chassis Mounted Rod Brackets

Tools Needed:

- All tools necessary to remove the bumper which may include: Torx 30 screwdriver, flat head screwdriver, clip remover, etc.
- Level
- 10mm wrench
- 10mm socket / ratchet wrench
- 1/4" drill bit
- Drill
- Level

Included in Kit:

- (2) Chassis brackets
- (4) M6-1.0 x 20mm hex flange bolts
- (4) M6-1.0 nyloc nuts
- (4) 1/4" small washers

Steps:

- 1.) This is an extremely short guide on where to install your chassis mounted rod brackets. Bumper removal is up to you. If you cannot figure out how to remove the bumper, go ahead and use online sources.

- 2.) Once the bumper is off you will need to remove the plastic pieces underneath. The “blinds” in front of the radiator can stay.

- 3.) The brackets will need to be installed onto the crash beam. There are two square holes on the right side that are slightly offset. The bracket will be installed into these spots. On the left side the lower hole will need to be drilled. Use a level to make sure the bracket will be installed vertically. Install the bolts pointing inward with ¼” small washers and nyloc nuts on the inside. Use the level to assure the brackets are perfectly vertical. Securely tighten the brackets so they cannot move.







4.) Reinstall the bumper and associated parts and you are done!!! Enjoy your new FS Performance Engineering aero! Be sure to use #FSPerformanceEngineering in the online world. For questions email costas@fspeinc.com or jim@fspeinc.com Or call/text us at (661) 809-0954