



Kia Forte (2019-2021) Rear Spats Installation Instructions

By FS Performance Engineering

Tools Needed:

- Cleaning spray/solution
- Wrag
- Masking tape
- Drill
- ¼" Drill Bit
- Marker
- Flat head screwdriver
- 10mm wrench
- 10mm socket
- Ratchet wrench
- Isopropyl alcohol (if you ordered edge trim)
- Diagonal cutters (if you ordered edge trim)

Included in Kit:

- (2) Rear Spats (left and right)
- (8) M6-1.0 x 20mm bolts
- (8) ¼" Small washers
- (8) ¼" ID, 1" OD washers
- (8) M6 Nyloc nuts

Steps:

- 1.) Begin by raising the rear of your car and place it on jack stands.
- 2.) Start with either spat - we started with the right side. Clean the mounting surface on the bumper where the spat will mount.



- 3.) Place masking tape onto the bumper where the spat will be mounted.



4.) Hold your spat up onto the car so the front edge is lined up with the back edge of the fender. Adjust where you'd like and mark the holes onto the bumper.



5.) Hold the spat firmly and mark the spat's holes onto the bumper. Remove the spat and make sure the marks are on the flat surface of the bumper - not too close to an edge. If they are, remark. See where we placed ours.



6.) Drill $\frac{1}{4}$ " holes in the bumper where the marks were made, then remove the tape.



7.) Use your flat head screwdriver to unclip the plastic push pin shown (3rd one from front). The plastic support above is now loose so you can access the above side of the bumper.



8.) Install your spat. Use the supplied bolts pointing upward. Place the larger washers on bottom, and small washers above the bumper with nyloc nuts. Mount securely.





9.) Reinstall your push clip to hold the plastic support.

10.) If you purchased edge trim, clean the edges of the spat with your isopropyl alcohol and wrag. Place the edge trim on top and cut it to size with diagonal cutters. Use a heat gun if needed to form around corners.



11.) Repeat this on the other side of the car.

12.) Enjoy your new rear spats for the Kia Forte! If you have any questions feel free to reach out.

Email: Costas@fspeinc.com

Phone: +1 661-809-0954

