



Model 3 Rear Spats Installation Instructions

By FS Performance Engineering

Hi there! Thank you for purchasing our Tesla Model 3 rear spats and joining the FSPE team.. Installation is extremely simple and should take 5-10 minutes. Enjoy!

Tools Needed:

- 10mm wrench or socket + ratchet wrench
- Car cleaning spray + wrag

Included in Kit:

- (2) Rear Spats w/ applied double sided tape

Steps:

- 1.) Start on one side of the car. Identify the 2 bolts behind the rear wheel under the bumper. Remove them with your 10mm wrench.



2.) Use your cleaning solution and wrag to wipe the underside clean of dirt/debris.



3.) Remove your rear spats from their clear wrap. Identify the rear spat for the side of the car you are working on.

→ If you have aluminum spats they are symmetrical.

→ If you have carbon fiber spats there is a left and right.

Then peel off the tape film.



4.) Push the car's bolts upward through the spats and line them up with the holes in the car where the bolts were removed. Securely tighten with your 10mm wrench. The 3M tape will make contact with the underside of the bumper.





5.) Repeat this on the other side of the car.

6.) ENJOY YOUR NEW SPATS. Feel free to contact us with any questions you might have!

Phone: 661-809-0954

Email: costas@fspeinc.com

