

## **FS Performance Engineering**

Subaru Impreza Hatchback (2016-2019) Front Lip/Splitter Installation Instructions

## **Tools/Items Needed:**

- Cordless drill
- 1/4" drill bit
- Flat head screwdriver
- Phillips head screwdriver
- (2) 10mm wrenches/sockets
- A friend! (hopefully not a tool)
- Marker/pencil

## **Included in Kit:**

- (1) Front lip/splitter
- (16) M6-1.0 x 12mm bolts
- (16) M6-1.0 nuts



## **Steps:**

- 1. Raise car and secure with jack stands.
- 2. Remove the (very) large splash tray from under the engine using your flat head screwdriver and phillips head screwdriver. There should be 15 clips (use flat head) and 4 bolts (use phillips head) it's like a treasure hunt! You'll find them around the front bumper, at the center of the tray, up the sides near the tires, and at the rear of the tray. Place tape underneath the center of the front bumper.





3. With help from a friend, and possibly a table or something underneath the front bumper, hold the front lip/splitter up against the bumper. <u>Center</u> the lip/splitter and push the left and right ends up against the plastic pieces that guard the tires. Mark the two holes at the center of the lip/splitter onto the tape using a marker or pencil.







4. Drill out the two holes just marked with your cordless drill and  $\frac{1}{4}$ " drill bit. Drop two M6-1.0 x 12mm bolts down into the holes and install the front lip/splitter with two M6-1.0 nuts. Feel free to install the bolts facing up or down. Tighten them securely, but not so much that it shreds the bumper.





5. Drill one hole at a time through the splitter and into the bumper. Install a bolt/nut every time you drill a hole. We secured the two outer ends first, then drilled and installed the rest of the bolts/nuts in between. Tighten them securely, but not so much that it shreds the bumper.





6. Reinstall your splash tray (15 clips, 4 bolts).



6. Enjoy your new FS Performance Engineering front lip/splitter! Remember to send us pictures once it is installed.



For questions email <u>costas@fspeinc.com</u> or <u>jim@fspeinc.com</u> Or call/text us at (661) 809-0954