

## Toyota Camry (2018-2024) Chassis Mounted Front Splitter Packing List

### **TOOLS NEEDED**

- 10mm Socket
- 3/32" Allen Wrench
- 3/8" Socket
- 7/16" Socket & Wrench
- 1/2" Socket & Wrench
- Drill w/ Socket Attachment
- Ratchet Wrench
- Flat Head Screwdriver
- Isopropyl Alcohol
- Diagonal Cutters
- Clean Rag
- Exacto Knife
- Scissors

### **PARTS SUPPLIED**

- (1) 2-Piece Splitter      (1) Air Dam (2-piece)  
(1) Logo Plate            (1) Chassis Bracket

### **HARDWARE SUPPLIED**

#### **BAG 1 (chassis bracket)**

- A16 - (3)** M6-1.0 x 55mm Hex Bolts  
**B31 - (3)** 1/4"x1" Washers  
**D26/D27 - (3)** 30mm Spacers

#### **BAG 2 (air dam connection)**

- B24 - (2)** 1/4"-20 Nyloc Nuts  
**B31 - (2)** 1/4" x 1" Hex Bolts

#### **BAG 3 (logo/splitter)**

- Yellow Bins - (4)** Low Profile 10-24 x 3/8" SS Bolts  
**B03 - (2)** 10-24 Zinc Nyloc Nuts  
**Cut - (1)** Small White Vinyl Patch

#### **BAG 4 (splitter big bolts)**

- B34 - (16)** 5/16-18 x 1" Hex Bolts  
**D16 - (16)** 5/16 x 1.25" Washers

#### **BAG 5 (splitter/air dam)**

- B10 - (8)** 1/4"-20 x 1" Hex Bolts  
**B31 - (8)** 1/4" x 1" Washers  
**D32 - (1)** Blue Threadlocker

#### **ITEMS 6 & 7**

- (10 Feet)** Thick Edge Trim BLACK  
**(10 Feet)** Splitter Edge Trim of Choice



Scan here for video installation instructions: