



Toyota Camry TRD (2020-24) Mudguards Packing List / Installation Instructions

Parts:

- (2) Front Mudguards
- (2) Rear Mudguards

Hardware:

- (4) Metal U Clips
- (2) 10-32 x 1.25" hex bolts
- (2) 10-32 well nuts
- (2) 7/16" washers

Installation Instructions - Scan This QR Code:



UPDATE TO INSTRUCTIONAL VIDEO: See pics on next pages.

- The rear mudguards require the supplied 10-32 hardware.
- The rear U-clips must be “opened up” using two flat head screwdrivers if they are not already pried open.
- The rear mudguard pop clip will be TIGHT.

Rear mudguard middle clip

REMOVE THE CLIP:



INSERT WELL NUT:



WELL NUT INSERTED:



INSTALL BOLT/WASHER



Make sure you're pushing the guard up against the car when tightening the bolt. Stop when it feels very snug and cannot be pulled back out. Get help from a friend here!