



Toyota Camry TRD (2020-24) Rear Spats Packing List / Installation Instructions

Parts:

- (1) Left Spat
- (1) Right Spat

Hardware:

- (6) M6-1.0 x 20mm Hex Head Flange Bolts
- (6) ¼" x 1" Washers
- (6) ¼" x ⅝" Washers
- (6) M6-1.0 Nyloc Nuts

Installation Instructions - Scan This QR Code:

