# **FS** Performance Engineering

## 1991-1998 MK3 Volkswagen Golf/GTI Diffuser Installation Instructions

#### **Tools Needed:**

10 mm Wrench or Socket + Ratchet Wrench

### Included in Kit:

- (1) Diffuser
- (3) <sup>1</sup>/<sub>4</sub>"x2" Washers
- (3) M6mm x 30mm Hex Head Bolts

#### Steps:

- 1. Raise car and secure with jack stands.
- 2. Using the 10 mm wrench or 10 mm socket + ratchet wrench, remove the three bottom bumper bolts. Optional remove tow hook cover on right side of rear bumper for aesthetic appeal (removed in picture).



3. Hold the diffuser in place aligning the holes in the diffuser with the holes in the rear bumper. This might be easier with help from a friend. Install the supplied bolts and washers to hold the diffuser to the car, but do not tighten at this time.



4. Align the diffuser so that it is even on each end of the bumper. Tighten the bolts (no torque specification but do not overtighten) and adjust as necessary (optional: green or blue thread locker – results in more removal).



5. Enjoy your new diffuser!

