



FS Performance Engineering

Volkswagen MK7 Golf R Side Extension Installation Instructions

Tools Needed:

- T25 torx driver
- Phillips head screwdriver
- Cordless drill
- 5/64" diameter drill bit

Included in Kit:

- (2) Front side extensions
- (2) Rear side extensions
- (2) Short screws
- (2) Long screws

Steps:

1. Raise car and secure with jack stands.
2. Turn your steering wheel all the way to the right.
3. Starting at the front passenger side identify and remove the Torx 25 screw holding the rocker panel to the fender lining. Using the Torx 25 screw just removed, install the front passenger side extension in the desired position (we recommend all the way toward the outside of the car). Tighten securely but not so much to strip any plastic. See the illustration below.



4. Identify the hole on the underside of the front passenger extension. Adjust the extension so it is flush with the outside of the rocker panel and drill a small (5/64") hole into the bottom of the rocker panel. Fasten the extension using a supplied short screw. Tighten securely (while being sure to push up) but not so much to strip away any plastic.



5. Turn your steering wheel to the left and repeat steps (3.) and (4.) on the driver's side.

6. Starting on the passenger side identify the Torx 25 screw at the rear underside of the rocker panel. Remove and hold onto it for later use. Install the rear passenger side extension using a supplied long screw. This long screw takes place of the screw just removed. Position the extension in the desired position and tighten securely but not so much that it causes the extension to bend.





7. Adjust the rear extension so it is flush with the rocker panel. Identify the hole on the underside of the rear side extension and drill a small hole (5/64") into the bottom of the rocker panel. Fasten the extension using the screw initially removed in step (6.). Tighten securely but not so much to strip any plastic.

8. Repeat steps (6.) and (7.) on the driver's side.

9. Enjoy your new FS Performance Engineering Side Extensions!



For questions email costas@fspeinc.com or jim@fspeinc.com
Or call/text us at (661) 809-0954