

# REVIVAL CYCLES

M.UNIT EXAMPLE  
DIAGRAM FOR  
KICKSTART ONLY  
SYSTEM WITH  
MECHANICAL  
POINTS OR  
TRANSISTORIZED  
IGNITION

This diagram is intended to be a general example to demonstrate how these components can be integrated to create a reliable, modernized electrical system. There are certainly other ways to approach wiring an m.Unit, some good, some bad. This is a technique we know to be reliable.

WIRE GAUGE  
MAX AMPERAGE  
QUICK REFERENCE

AWG	AMPS
22	5
20	10
18	15
16	20
14	30
12	40
6	100+



REVIVALCYCLES.COM

