

SELF ADHESIVE BROOM HOLDER

INSTALLATION & OPERATION
INSTRUCTIONS



JS JACKSONSUPPLIES

Step 1

Clean the wall. Make sure there is no dust, grease, or water on the wall's surface where you plan on installing your new broom holder.



Step 2

Remove the backing that covers the adhesive tape.



Step 3

Place the broom holder against the wall and press down firmly with your hand. Allow the broom holder to adhere to the surface for 24-hours before using.

