

**NOTE: Read instructions thoroughly before installation!**

## **TOOLS NEEDED FOR INSTALLATION:**

Wrench or pliers, rags and thread seal tape.

When using a wrench or pliers, always protect finishes by wrapping parts with a cloth.

## **STEP-BY-STEP INSTALLATION INSTRUCTIONS:**

1. Remove the old flange, using screwdriver to carefully pry it away from the wall.
2. Remove the old arm by using a wrench to turn it counter-clockwise.
3. Slide the new flange onto the new shower arm. Wrap threads on one end of the arm with thread seal tape in a clockwise direction (see fig. 1).
4. Screw the taped end of the arm into plumbing connection inside the wall. Hand-tighten (see fig. 2).
5. Wrap the arm with a cloth to avoid scratches, then finish tightening with a wrench (see fig. 3).
6. Push flange against the wall. Wrap the remaining threads of the shower arm with thread seal tape as in step #3.
7. Install the showerhead. Tighten by hand, then wrap the showerhead with a cloth and finish tightening with a wrench.

