



SAFEDRIVE PRO™ FOOT REST INSTALLATION INSTRUCTIONS



The SafeDrive Pro Foot Rest is an optional add-on to the SafeDrive Pro passenger side brake system and is designed to be installed on the right side of the SafeDrive Pro. It consists of an Attachment Prop, the Foot Rest, and one wing nut to customize the placement and angle of the Foot Rest. It can be adjusted forward, backward, up, down, and selective angles.

To install the SafeDrive Pro Foot Rest:

1. Unscrew the two chrome nuts on the right base of the SafeDrive Pro using a 14mm or 9/16ths socket (brake pedal facing towards you).
2. Place the Attachment Prop over the screws where the chrome nuts were removed and replace the chrome nuts and tighten down.
3. Using the included wing nut, attach the Foot Rest to the Attachment Prop as shown to the users preferred setting. The wing nut screw will only fit into one of the four larger holes.

Attach the Attachment Prop over the screws with chrome nuts removed and tighten down the nuts.	Adjust the distance and height of the foot rest by selecting one of the four larger holes. Use the wing nut to secure.	Pull the quick adjustment ring out, adjust the angle, and release it to lock the pin into the new position.
		