

What's included:

- (2) Two rear DuroBumps
- (2) Two JIS 10.9 M8-1.25 50 mm flange bolt
- (1) One FREE sticker

Tools Required:

- Jack and jack stands
- 12 mm socket wrench
- 19 mm deep socket wrench or lug wrench
- Scraper or wire brush to clean debris
- Torque wrench

Instructions:

Step 1: Following vehicle manufacturer recommendations, use a properly rated jack. Lift the rear of the truck with floor jack and support the frame rails with jack stands. Remove rear wheels. **Be sure to use jack stands!**

Step 2: Remove the OEM bump stop located on the frame rail above the rear axle tube, using a 12 mm deep socket.

Step 3: Use a scraper or wire brush to clean any mud/debris from the frame.

Step 4: Insert the flange bolt into the mounting hole of the DuroBumps. Mount DuroBumps in OEM location using a 12 mm socket wrench until snug. **Do not over tighten.**

Step 5: Repeat steps 2 – 4 on the other side.

Step 6: Reinstall wheels and lower vehicle back to the ground. Torque lug nuts to factory specifications.

Now go hit some trails or cruise the mall ... whatever you're into!



MADE IN THE U.S.A.
www.DuroBumps.com