



The smartest way to attach almost anything to shipping containers

Plywood Adapter drawing



Notes

Use these drawings to make your own plywood adapters.

The overall size of the plywood can be changed but the hole distances from each other must remain the same.

Fabricate from 30mm Birch ply or suitable synthetic alternative.

Use in conjunction with 2no. M12x45mm countersunk screws.

CAD Drawing can be downloaded from:
www.dominoclamps.com/pages/downloads

Technical Drawings

