

RA Neoteric Lighting Design



Assembly and Installation Instructions for Model

500420DW

CAUTION - RISK OF FIRE

Installation of this fixture should be done by a licensed electrician or by a person familiar with local electrical codes and the construction and operation of this fixture.

Warning please make sure the electrical breaker is shut off before commencing with this installation Read and familiarize yourself with these instructions before commencing

This fixture is certified for wall mounting and is suitable for Wet locations and dimmable with most dimmers.

Package Contents		
Part	Description	Qty
Α	Mounting plate	1
В	Junction-Box mounting screws	2
С	Electrical wire connectors	3
D	Base rubber gasket	1
Е	Fixture assembly	1
F	Fixture mounting nuts	2
G	Fixture shroud	1
Н	Shroud lock screw	1

Installing the fixture please ensure the electrical breaker is switched off before commencing

- Attach the supplied Mounting plate (A) with the two supplied mounting screws (B) to the Junction-Box.
- Attach the supplied Base rubber gasket **(D)** to the back rim of the Fixture Assembly **(E)**
- Connect the supply wires to the fixture wires using the supplied Electrical wire connectors **(C)**. White supply wire to the White fixture wire, Black supply wire to Black fixture wire and the ground Bare Copper or Green wire to the Green fixture wire. Once the electrical wire connectors are securely fastened it is recommended to tape these connectors with electrical tape.
- Attach the Fixture Assembly **(E)** to the Fixture mounting bracket **(A)** and secure with supplied Fixture mounting nuts **(F)**.
 - Attach the Fixture shroud (G) to the Fixture assembly (E). This fixture has been designed for the Fixture shroud to the bottom or top of The Fixture assembly. Once in position lock in place with the Shroud lock screw (H).
- Switch on the electrical breaker switch and your new fixture is ready for many years of trouble free use



