



Hide Assembly Instructions

Things to have before starting assembly:

- Phillips screwdriver or drill
- Flat surface to build on

Please note

- All the stickers should be inside of the hide once you finish assembling.
- If using a drill, take care not to over-drill into the pilot hole

Assembly: To ensure proper fit, assemble all pieces together before screwing together

- Attach Front to Left Side:
 - Align and connect the Front with the Left Side, interlocking the cutouts.
 - Ensure the grooved ledge faces upward.
- Attach Front to Right Side:
 - Align and connect the Front with the Right Side, interlocking the cutouts.
 - Ensure the grooved ledge faces upward.
- Attach Back to Right & Left Sides:
 - Interlock the cutout notches on the Back with the Right and Left Sides.
 - This may require some effort to achieve a snug fit.
- Attach Top:
 - Place the Top onto the grooved ledge.
- Secure Sides & Top:
 - Screw all pieces together using 1" screws in pilot holes
 - If using a drill, take care not to over-drill into the pilot hole
- Final Steps:
 - Remove any protective wrapping on the outside of the hide.
 - Remove all stickers from inside the hide.
- Share on Social Media:
 - Snap pictures or share a video on Instagram or Facebook using the hashtags #reptilekages and @reptilekages.

Thank you so much for your order!

KAGES

www.ReptileKages.com | CustomerService@ReptileKages.com