

Installation guide for 3R harness



- 1- Place the grey straps around the rawhide at the bottom of the foot opening

2- Insert the screws through the holes at the front of the footplate of the harness.





3- Fold the grey straps in half, so you can pass the screws through the harness and the straps



4- Insert the crampon and screw the bolts to close the harness system.



5- A look at the final product !